

Touch Free Hand Sanitizer Installation Instructions

- 1) Attach the pump to your gallon sanitizer - do not prime



- 2) Remove cover from back of station by lifting the back cover up and away using finger-holes



- 3) Depress the pump and insert top into the back of the station by lining up pump spout with pre-drilled hole



- 4) Reattach back cover to unit and depress foot pedal to administer hand sanitizer



For resource documents including how to secure to the floor,
adjust dispensing amounts, warranty and safety information please visit
www.americangrowerresource.com/touch-free-hand-sanitizer-dispenser/